


Operation Manual

Nucleic Acid Isolation Device

QuickGene-Mini8L



Extraction Flow



Introduction

Thank you for purchasing the Nucleic Acid Isolation Device QuickGene-Mini8L (hereafter, called "QuickGene-Mini8L"). DNA can be easily extracted by using QuickGene-Mini8L.

This guide contains important information regarding the safe use of QuickGene-Mini8L. Read this manual carefully before using the device.

Keep this manual after reading it, for reference whenever necessary.

About Infectious Wastes

When handling or disposing of infectious materials, follow the laboratory guideline or the law regarding infectious waste to perform proper incineration, fusion, sterilization, and/or disinfection.

When you use a third party to dispose of it, outsource this work an operator licensed to handle medical waste subject to special control, and give them the manifest of the medical waste at the same time.



Universal biological
hazard symbol

■ Exclusion clauses

- The contents of this manual may be updated without notice.
- KURABO INDUSTRIES LTD. assumes no liability for infringement of third party copyrights or other rights arising from the use of any information in this manual.
- KURABO INDUSTRIES LTD. assumes no liability for device failures or damages due to remodeling, maintenance, and repairs performed by parties other than KURABO INDUSTRIES LTD. or agencies specified by KURABO INDUSTRIES LTD.
- KURABO INDUSTRIES LTD. assumes no liability for failures or damages due to use of third-party products.
- KURABO INDUSTRIES LTD. assumes no liability for device failures or damages due to remodeling, maintenance, repairs, etc. using repair parts other than genuine parts specified by KURABO INDUSTRIES LTD.
- KURABO INDUSTRIES LTD. assumes no liability for device failures or damages due to failure to observe the precaution and operation procedures described in this manual.
- KURABO INDUSTRIES LTD. assumes no liability for device failures or damages due to using the device in an environment that does not meet the operational requirements (power, installation environment, etc.) described in this manual.
- KURABO INDUSTRIES LTD. assumes no liability for device failures or damages due to natural disasters such as fire, earthquakes, floods, or lightning.
- No part of the contents of this manual may be reproduced without permission from KURABO INDUSTRIES LTD.

Notations

This manual contains important information regarding the safe use of QuickGene-Mini8L.

Read this information carefully before using QuickGene-Mini8L, and start operation.

The meanings of safety precaution marks are as follows:



WARNING:

"WARNING" indicates a dangerous condition that may lead to death or serious injury.



BIOHAZARD:

"BIOHAZARD" indicates exposure to a biological agent or condition that may be infectious or harmful.



CAUTION:

"CAUTION" indicates the possibility of danger that may lead to minor or moderate personal injury.

"CAUTION" may also indicate an accident of property damage.

Important:

"Important" shows the important notes for usage, as well as prohibited actions.

Note:

"Note" indicates the notes, procedures that should be obeyed, and supplementary information for use.

引言

感谢您购买核酸分离设备QuickGene-Mini8L（以下称为"QuickGene-Mini8L"）。使用QuickGene-Mini8L可轻松提取出DNA。

本手册中包含了有关QuickGene-Mini8L安全操作的重要信息，请在设备使用之前仔细阅读。
阅读完毕，请妥善保存本手册，以备必要时查阅。

关于传染性废料

处理或弃置传染性材料时，请遵照有关传染性废弃物的试验室准则或相关法律进行正确的焚化、熔解、杀菌和 / 或消毒。

如果是交由第三方来完成上述作业，则应将其外包给对特控医疗垃圾有处理许可权的操作人员，并同时移交相应的货单。



通用生物危害性
标记

■ 免责条款

- 本手册的内容如有更新，恕不事先通知。
- 对于因使用本手册中任何信息而导致侵犯第三方版权或其他权利的行为，KURABO INDUSTRIES LTD.恕不承担责任。
- 对于由非 KURABO INDUSTRIES LTD.或其指定机构所进行的改装、维护及维修等事宜，KURABO INDUSTRIES LTD.恕不对因此而导致的设备故障或损坏承担责任。
- 对于因使用第三方产品而导致的设备故障或损坏，KURABO INDUSTRIES LTD.恕不承担责任。
- 对于使用非 KURABO INDUSTRIES LTD.所指定的正品作为维修部件而进行的改装、维护及维修等事宜，KURABO INDUSTRIES LTD.恕不承担责任。
- 对于因不遵守本手册中所述的注意事项和操作规程而导致设备出现故障或被损坏的情况，KURABO INDUSTRIES LTD.恕不承担责任。
- 对于因设备工作环境（电源、安装环境等）不满足本手册中所述的操作要求而导致设备出现故障或被损坏的情况，KURABO INDUSTRIES LTD.恕不承担责任。
- 对于因火灾、地震、洪水或雷电等自然灾害而导致设备出现故障或被损坏的情况，KURABO INDUSTRIES LTD.恕不承担责任。
- 未经 KURABO INDUSTRIES LTD.许可，不得复制本手册中的任何部分。

标志

本手册中包含了有关QuickGene-Mini8L安全操作的重要信息。请在使用QuickGene-Mini8L之前仔细阅读，然后再进行操作。

安全注意事项的含义如下所述：



WARNING:

"WARNING" 指示发生时可导致死亡或严重伤害的危险情况。



BIOHAZARD:

"BIOHAZARD" 指示暴露于生物制剂或是面对可能具有传染性或危害性的情况。



CAUTION:

"CAUTION" 指示发生时可导致轻微或中度人身伤害的潜在危险。

"CAUTION" 还可指示意外财产损失。

Important:

"Important" 指示重要的使用说明及严禁的操作。

Note:

"Note" 指示注解信息、应遵守的操作规程及补充性的使用信息。

Introduction

Merci d'avoir acheté le Dispositif d'isolation d'acide nucléique QuickGene-Mini8L (appelé ci-après "QuickGene-Mini8L"). L'extraction de l'ADN peut être facilement effectuée à l'aide du QuickGene-Mini8L.

Ce guide contient des informations importantes concernant l'utilisation en toute sécurité du QuickGene-Mini8L. Lisez attentivement ce manuel avant d'utiliser l'appareil.

Après lecture, conservez ce manuel pour pouvoir vous y référer ultérieurement si nécessaire.

A propos des déchets infectieux

Lorsque vous manipulez ou mettez au rebut des produits infectieux, veuillez à respecter les directives du laboratoire ou la loi sur les déchets infectieux pour en effectuer l'incinération, la fusion, la stérilisation, et/ou la désinfection correctes.

Lorsqu'un tiers est chargé de la mise au rebut, veuillez à la confier à une entreprise habilitée à traiter les produits médicaux sujets à contrôle spécifique et à fournir en même temps le manifeste des produits concernés.



Universal biological
hazard symbol

■ Clauses d'exclusion

- Le contenu de ce manuel peut être mis à jour sans préavis.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable de la violation aux copyrights de tiers ou à d'autres droits émanant de l'utilisation d'une information quelconque contenue dans ce manuel.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages de l'appareil causés par la modification, la maintenance et les réparations effectuées par des tiers autres que KURABO INDUSTRIES LTD. ou des agences agréées par KURABO INDUSTRIES LTD.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages dus à l'utilisation de produits tiers.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages de l'appareil dus à la modification, la maintenance, les réparations, etc. utilisant des pièces de rechange qui ne sont pas des pièces d'origine spécifiées par KURABO INDUSTRIES LTD.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages de l'appareil dus à la non-observation des procédures de fonctionnement et des précautions décrites dans ce manuel.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages de l'appareil au cas où il est utilisé dans un environnement qui ne répond pas aux conditions de fonctionnement (alimentation, environnement de l'installation, etc.) décrites dans ce manuel.
- KURABO INDUSTRIES LTD. ne peut être tenu pour responsable d'une défaillance ou de dommages de l'appareil dus à des catastrophes naturelles, telles qu'un incendie, un tremblement de terre, des inondations ou des éclairs.
- Aucune partie de ce manuel ne peut être reproduite sans l'autorisation de KURABO INDUSTRIES LTD.

Conventions

Ce manuel contient des informations importantes concernant l'utilisation en toute sécurité du QuickGene-Mini8L.

Lisez attentivement ces informations avant d'utiliser et de faire fonctionner le QuickGene-Mini8L.

Les significations des symboles de sécurité utilisés sont les suivantes :



WARNING:

"WARNING" signale des conditions de dangerosité qui, si elles n'étaient pas évitées, pourraient entraîner la mort ou des blessures graves.



BIOHAZARD:

"BIOHAZARD" indique l'exposition à un agent biologique ou à une situation qui peut être infectieuse ou nocive.



CAUTION:

"CAUTION" signale un danger possible qui, s'il n'était pas évité, pourrait entraîner des blessures corporelles mineures ou légères.

"CAUTION" pourrait aussi indiquer un risque de dommage matériel.

Important:

"Important" signale des remarques importantes concernant l'utilisation et les actions interdites.

Note:

"Note" les remarques concernent les procédures à respecter, elles fournissent aussi des informations complémentaires.

Einführung

Wir danken Ihnen für den Kauf des Geräts zur Nukleinsäureisolierung QuickGene-Mini8L (im Folgenden als „QuickGene-Mini8L“ bezeichnet). Mit QuickGene-Mini8L können DNA leicht extrahiert werden. Diese Anleitung enthält wichtige Informationen zur sicheren Verwendung von QuickGene-Mini8L. Lesen Sie die Anleitung vor der Verwendung des Geräts sorgfältig durch. Bewahren Sie diese Anleitung nach dem Lesen zum späteren Nachschlagen auf.

Hinweise zu infektiösen Abfällen

Befolgen Sie bei der Handhabung oder Entsorgung von infektiösen Abfällen die Laborrichtlinien sowie die geltenden Gesetze und Vorschriften, und führen Sie die Verbrennung, Einschmelzung, Sterilisation und/oder Desinfektion entsprechend durch. Wenn Sie die Entsorgung durch Dritte ausführen lassen, beauftragen Sie zugelassene Entsorgungsfirmen für medizinischen Sondermüll, und stellen Sie ihnen die relevanten Informationen zur Sondermüll-Abfallbehandlung zur Verfügung.



Universal biological
hazard symbol

■ Ausschlussklauseln

- Der Inhalt dieser Anleitung kann jederzeit ohne Vorankündigung geändert werden.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Verletzungen von Copyright- oder anderen Rechten Dritter, die aus der Verwendung jeglicher Informationen dieser Anleitung entstehen können.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Geräte-Ausfälle oder -Beschädigungen, die durch Veränderungen, Wartung oder Instandsetzung entstehen, sofern diese nicht durch die KURABO INDUSTRIES LTD. oder von der KURABO INDUSTRIES LTD. genannte Auftragnehmer durchgeführt wurden.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Ausfälle und Beschädigungen, die durch Verwendung von Produkten von Drittherstellern verursacht wurden.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Geräte-Ausfälle und -Beschädigungen, die durch Veränderungen, Wartung, Instandsetzung usw. unter Verwendung von Ersatzteilen verursacht wurden, die nicht von der KURABO INDUSTRIES LTD. angegebene Originalteile sind.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Geräte-Ausfälle und -Beschädigungen, die auf die Nichtbeachtung der in dieser Anleitung beschriebenen Vorsichtsmaßnahmen und Betriebsverfahren zurückzuführen sind.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Geräte-Ausfälle und -Beschädigungen, die auf den Betrieb des Geräts unter Bedingungen zurückzuführen ist, die den in dieser Anleitung beschriebenen Betriebsanforderungen (Stromversorgung, Betriebsumgebung etc.) nicht entsprechen.
- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für Geräte-Ausfälle und -Beschädigungen, die auf Naturkatastrophen wie Feuer, Erdbeben, Überschwemmung oder Blitzschlag zurückzuführen sind.
- Kein Teil dieser Anleitung darf ohne Erlaubnis der KURABO INDUSTRIES LTD. reproduziert werden.

Warnhinweise

Diese Anleitung enthält wichtige Informationen zur sicheren Verwendung von QuickGene-Mini8L.

Lesen Sie diese Informationen sorgfältig durch, bevor Sie QuickGene-Mini8L in Betrieb nehmen.

Die Bedeutung der verschiedenen Sicherheitshinweise wird im Folgenden erläutert:



WARNING:

„**WARNING**“ weist auf gefährliche Betriebsbedingungen hin, die zu ernsthaften Verletzungen oder Verletzungen mit Todesfolge führen können.



BIOHAZARD:

„**BIOHAZARD**“ kennzeichnet die Gefährdung durch biologische Agenzien oder Verhältnisse, die infektiös oder gesundheitsschädlich sein können.



CAUTION:

„**CAUTION**“ weist auf gefährliche Betriebsbedingungen hin, die zu leichten bis mittleren Verletzungen führen können.

„**CAUTION**“ kann darüber hinaus das Risiko einer Sachbeschädigung kennzeichnen.

Important:

„**Important**“ kennzeichnet wichtige Bedienungshinweise sowie zu unterlassende Vorgehensweisen.

Note:

„**Note**“ kennzeichnet Hinweise, Vorgehensweisen, die befolgt werden sollten, und zusätzliche Informationen zur Bedienung.

Safety Information

This chapter describes safety precautions.

For your safety and that of others, follow the guidelines provided in the following pages concerning the use of QuickGene-Mini8L.

About Mark

Check all descriptions with the  mark attached.

About Instrument



WARNING:

- **Ignoring the following notations may lead to fire or electric shock.**
 - In countries other than US and Canada, do not use the power cable attached for the US and Canadian models.
 - In countries other than US and Canada, use a power cable that meets your country's standard, or contact your local distributor.
 - Use the AC adapter provided.
 - Do not use the power cable attached for the US and Canadian models for other products.
 - Do not use QuickGene-Mini8L with voltage other than the voltage specified on the device.
Do not overload the power outlet with too many devices.
 - Do not use QuickGene-Mini8L with a damaged power plug or a loose socket.
 - If there is dust on the prongs of the power plug or on the plug socket, remove it with a dry cloth.
 - When you disconnect the plug from the outlet, be sure to hold the power plug itself. Do not pull the power cable.
 - For maintenance, disconnect the power plug from the outlet.
 - Do not touch the power plug when you hear the crash of thunder.
- **Do not pour any liquid on QuickGene-Mini8L. Do not place any objects containing liquid on QuickGene-Mini8L. Doing so may cause a device failure, fire, or electric shock.**
- **In the event the device overheats, starts to smoke or smells strange, immediately unplug the power cable.**



CAUTION:

- **Never attempt to remodel QuickGene-Mini8L without the manufacturer's permission. Doing so may cause fire or electric shock.**
- **Do not place or drop objects on QuickGene-Mini8L. Also refrain from bumping or knocking it, as doing so may cause a failure or malfunction.**
- **If any liquid materials are left inside the device, wipe it up a soft paper tissue, etc. Otherwise, QuickGene-Mini8L may be damaged.**
- **When replacing the pressure heads, be sure to wear gloves.**
- **If ethanol is spilled inside the device, immediately unplug the power cable.**
- **Repairs to QuickGene-Mini8L should only be performed by such agencies as are specifically authorized by KURABO INDUSTRIES LTD.**
- **Only original the KURABO INDUSTRIES LTD. replacement parts should be used.**
- **If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.**

About Isolation Kits

Referred to as “kit/kits” hereafter in this section.



CAUTION:

- When handling any of the kits, refer to the respective handbook.
- Reagents in each kit should be handled by observing the safety information and precautions regarding the kit.
- Extraction should be performed in an appropriate laboratory or workplace.

Isolation kits

For DNA	DNA whole blood kit/DB-L
	DNA tissue kit/DT-L

Noted: The kits are not supplied with QuickGene-Mini8L. Select the desired kit and order it separately.

About Reagents Not Included in the Kits



CAUTION:

- When handling any reagent not included in the kits, observe the safety information and precautions of the reagent.
- Extraction should be performed in an appropriate laboratory or workplace. Some reagents should be handled in a draft chamber.

About Cleaning/Washing Solution



CAUTION:

- For handling any cleaning/washing solution for the QuickGene-Mini8L and accessories, observe the safety information and precautions regarding the solution.
- Keep ethanol away from fire. It is highly flammable.



BIOHAZARD :

- Always wear appropriate gloves, a mask, and safety goggles when cleaning/washing.

About Samples



BIOHAZARD :

- Always wear appropriate gloves, a mask, and safety goggles etc. when handling any infectious samples.

Product Use Limitations

- **The KURABO INDUSTRIES LTD. assumes no liability for results regardless of the application.**
- **It is the user's responsibility to validate the performance of the Isolation Kits and QuickGene-Mini8L.**
- **QuickGene-Mini8L is a device for research and study only.**

When you use QuickGene-Mini8L, read this manual thoroughly and follow the safety management regulations of your facilities (laboratory).

安全信息

本章介绍安全注意事项。

为了您和他人的安全，请遵守下文中有使用QuickGene-Mini8L方面的指导原则。

关于 标记

请确认所有附带  标记的说明。

关于设备



WARNING:

- 忽视以下标志可能导致火灾或电击。
- 在美国和加拿大以外的国家和地区，请勿使用美国和加拿大机型所附带的电源线。
- 在美国和加拿大以外的国家和地区，请使用符合该地区标准的电源线，或与当地经销商联系。
- 请使用附带的电源适配器。
- 请勿将美国和加拿大机型附带的电源线用于其它产品。
- 电压未满足设备指定值时，不要使用 QuickGene-Mini8L。电源插座上不要插接过多设备，以免过载。
- QuickGene-Mini8L 不得使用破损的插头或松垮的插座。
- 如果在电源插头片或插座上有灰尘，请用干布将其去除。
- 从插座上拔下插头时，务必握住插头本身，切勿扯拽电源线。
- 维护时，应从插座上拔下电源插头。
- 打雷时不要触碰电源插头。
- 不要将任何液体泼溅到 QuickGene-Mini8L 上，不要在 QuickGene-Mini8L 上放置任何含有液体的物品。否则可能导致设备故障，或者引起火灾或电击。
- 如果设备过热，开始冒烟或发出异味，应立即拔下电源线。



CAUTION:

- 未经制造商允许，切勿试图改装 QuickGene-Mini8L。否则可能引起火灾或电击。
- 不要在 QuickGene-Mini8L 上放置物品或者将物品丢到 QuickGene-Mini8L 上，同时禁止撞击或敲打 QuickGene-Mini8L，否则将可能导致其出现故障。
- 如果设备内附着有液体，请用柔软的纸巾等进行擦拭，否则将可能损坏设备。
- 更换压头时，请务必戴手套。
- 如果有乙醇被洒到设备内部，应立即拔下电源线。
- 只有 KURABO INDUSTRIES LTD.指定的授权机构才能承担本装置的维修事宜。
- 只能使用 KURABO INDUSTRIES LTD.的原装更换部件。
- 如果使用该设备时，没有按照经销商所指定的方式而造成设备故障或损坏，将可能使设备附带的保修失效。

关于 QuickGene 专用试剂盒

在本章节以下部分中简称为“试剂盒”。



CAUTION:

- 使用各种试剂盒前，请仔细阅读试剂盒所附属的使用手册。
- 使用各种试剂盒前，请遵守关于该试剂盒的安全信息以及安全注意事项。
- 核酸提取操作，应在符合标准的相应实验室或工作场所进行。

专用核酸提取试剂盒

提取 DNA	DNA 全血提取试剂盒／DB-L
	DNA 组织提取试剂盒／DT-L

注意：以上试剂盒不包含在 **QuickGene-Mini8L** 之中。请根据样品选择合适的试剂盒并单独订购。

关于 QuickGene 专用试剂盒中未包含的一般试剂



CAUTION:

- 使用专用试剂盒中未包含的其它试剂时，需遵守关于此类试剂的安全信息及注意事项。
- 试剂的各项操作应在相应的实验室或者工作场所进行。某些特殊试剂按照标准在通风环境下进行操作。

关于清洁、清洗用的洗涤剂



CAUTION:

- 关于清洁、清洗装置及其附属品时使用的洗涤剂，需遵守各洗涤剂的使用安全注意事项。
- 乙醇类等易燃试剂，使用时需远离火源。



BIOHAZARD :

- 清洁、清洗装置时，需穿戴合适的手套、面具以及护目镜。

关于样品



BIOHAZARD :

- 处理任何可能具有感染性的样品时，请务必按照相应规定穿戴合适的手套、面具和护目镜。

使用上的限制

- 无论使用目的或应用情况如何， **KURABO INDUSTRIES LTD.** 不对结果承担任何责任。
- 对于各种样品的样品条件、性能的确认，需使用者自行负责测试与验证。
- **QuickGene-Mini8L** 为科研目的的设备。

使用 QuickGene-Mini8L 时，

请仔细阅读本手册并遵守所在单位（实验室）的安全管理规程进行各项操作。

Informations concernant la sécurité

Ce chapitre décrit les précautions de sécurité.

Pour votre sécurité et celles des autres, veuillez suivre les indications fournies dans les pages suivantes et qui concernant l'utilisation du QuickGene-Mini8L.

A propos de Mark

Vérifiez toutes les descriptions de la marque  fournies.

A propos des instruments



WARNING :

- **Si les recommandations suivantes ne sont pas prises en compte, un incendie ou une décharge électrique peut se produire.**
 - En dehors des Etats-Unis et du Canada, n'utilisez pas le câble d'alimentation fourni avec les modèles vendus aux Etats-Unis et au Canada.
 - En dehors des Etats-Unis et du Canada, utilisez un cordon d'alimentation conforme aux réglementations de votre pays ou contactez votre revendeur local.
 - Utilisez l'adaptateur secteur fourni.
 - N'utilisez pas sur d'autres produits le câble d'alimentation fourni avec les modèles vendus aux Etats-Unis et au Canada.
 - N'utilisez pas le QuickGene-Mini8L avec un voltage différent de celui spécifié sur l'appareil.
 - Ne branchez pas trop d'appareils sur la prise électrique.
 - N'utilisez pas le QuickGene-Mini8L si la fiche est endommagée ou si la prise n'est pas solidement fixée.
 - Si de la poussière recouvre les broches de la prise ou de la fiche, retirez-la à l'aide d'un chiffon sec.
 - Lorsque vous retirez la fiche de la prise, faites-le en tenant fermement la prise. Ne tirez pas le câble.
 - Pour tout entretien, débranchez la fiche de la prise murale.
 - Ne touchez pas la fiche lorsque le tonnerre gronde.
- **Ne versez aucun liquide sur le QuickGene-Mini8L. Ne placez aucun objet contenant du liquide sur le QuickGene-Mini8L. Vous risquez, en le faisant, de provoquer une panne, un incendie ou une décharge électrique.**
- **En cas de surchauffe de l'appareil, ou s'il dégage de la fumée ou une odeur bizarre, débranchez immédiatement le câble d'alimentation.**



CAUTION:

- **N'essayez en aucun cas de modifier le QuickGene-Mini80 sans l'autorisation du fabricant. Cela pourrait entraîner un incendie ou une décharge électrique.**
- **Ne placez et ne faites tomber aucun objet sur le QuickGene-Mini8L. De même, évitez de lui faire subir des chocs ou des coups, cela pourrait entraîner des défaillances et un mauvais fonctionnement du QuickGene-Mini8L.**
- **Si un quelconque liquide s'introduit dans l'appareil, épongez-le avec une serviette en papier, etc. Sinon, le QuickGene-Mini8L pourrait être endommagé.**
- **Lorsque vous remplacez les têtes de pression, veuillez à porter des gants.**
- **Si de l'éthanol est renversé à l'intérieur du dispositif, débranchez immédiatement le câble d'alimentation.**
- **Des réparations du QuickGene-Mini8L ne doivent être effectuées que par des agences spécifiquement autorisées par KURABO INDUSTRIES LTD.**
- **Seules les pièces détachées originales provenant de KURABO INDUSTRIES LTD. doivent être utilisées.**
- **Si ce matériel est utilisé de manière non spécifiée par le fabricant, la protection fournie par le matériel peut s'en trouver diminuée.**

À propos des kits d'isolation

appelés ci-après “kit/kits” dans cette section.



CAUTION:

- Lorsque vous manipulez l'un de ces kits, consultez le manuel respectif.
- Les réactifs de chaque kit doivent être manipulés en respectant les consignes de sécurité et les précautions relatives au kit.
- L'extraction doit être effectuée dans un laboratoire ou un lieu approprié.

Kits d'isolation

Pour l'ADN	Kit ADN sang total / DB-L
	Kit ADN tissu / DT-L

Note:

les kits ne sont pas fournis avec QuickGene-Mini8L. Sélectionnez le ou les kits de votre choix et commandez-les séparément.

À propos des réactifs non inclus dans les kits



CAUTION:

- Lorsque vous manipulez l'un des réactifs non inclus dans les kits, respectez les consignes de sécurité et les précautions relatives aux réactifs.
- L'extraction doit être effectuée dans un laboratoire ou un lieu approprié. Certains réactifs doivent être manipulés dans une enceinte pare-vent.

À propos de la solution de nettoyage



CAUTION:

- Pour manipuler une solution de nettoyage du QuickGene-Mini8L et de ses accessoires, respectez les consignes de sécurité et les précautions relatives à la solution.
- Éloignez l'éthanol de toute source d'incendie. Il est hautement inflammable.



BIOHAZARD :

- Portez toujours des gants appropriés, un masque et des lunettes de protection lorsque vous procédez au nettoyage.

À propos des échantillons



BIOHAZARD :

- Portez toujours au minimum des gants appropriés, un masque et des lunettes de protection lorsque vous manipulez des échantillons infectieux.

Limitations d'utilisation du produit

- **KURABO INDUSTRIES LTD. n'assume aucune responsabilité de résultats quelle que soit l'application.**
- **Il est de la responsabilité de l'utilisateur de valider les performances des Kits d'isolation et QuickGene-Mini8L.**
- **QuickGene-Mini8L est un appareil uniquement destiné à la recherche et l'étude.**

Lors de l'utilisation du QuickGene-Mini8L, lisez d'abord ce manuel entièrement et respectez les règlements de gestion de risque de votre lieu de travail (laboratoire).

Sicherheitsinformationen

In diesem Kapitel sind die Sicherheitsmaßnahmen beschrieben.

Um Verletzungen zu vermeiden, befolgen Sie bitte die Bedienungsrichtlinien für QuickGene-Mini8L auf den folgenden Seiten.

Informationen zum -Zeichen

Prüfen Sie alle Beschreibungen, die mit dem  -Zeichen versehen sind.

Informationen zum Gerät



WARNING:

- **Bei Missachtung der folgenden Warnhinweise besteht Brand- und Stromschlaggefahr.**
 - Verwenden Sie das beiliegende, nur für amerikanische und kanadische Modelle geeignete Netzkabel nicht außerhalb der USA und Kanada.
 - Verwenden Sie außerhalb der USA und Kanada ein Netzkabel, das Ihrer Landesnorm entspricht, oder wenden Sie sich an Ihren lokalen Händler.
 - Verwenden Sie das mitgelieferte Netzteil.
 - Verwenden Sie das beiliegende, nur für amerikanische und kanadische Modelle geeignete Netzkabel nicht für andere Produkte.
 - Betreiben Sie QuickGene-Mini8L ausschließlich mit der am Gerät angegebenen Netzspannung. Überlasten Sie die Steckdose nicht durch Anschließen von zu vielen Geräten.
 - Verwenden Sie QuickGene-Mini8L nicht mit einem beschädigten Netzstecker oder einer lockeren Steckdose.
 - Falls die Kontakte des Netzsteckers oder die Steckdose staubig sind, entfernen Sie den Staub mit einem trockenen Tuch.
 - Wenn Sie den Netzstecker aus der Steckdose ziehen, fassen Sie stets den Netzstecker direkt an. Ziehen Sie nicht am Netzkabel.
 - Ziehen Sie vor der Durchführung von Wartungsarbeiten den Netzstecker ab.
 - Fassen Sie den Netzstecker bei Gewitter nicht an.
- **Verschütten Sie keine Flüssigkeiten über QuickGene-Mini8L. Stellen Sie keine Flüssigkeitsbehälter auf QuickGene-Mini8L ab. Dadurch könnte es zu einem Ausfall des Gerätes, zu einem Brand oder Stromschlag kommen.**
- **Wenn sich das Gerät überhitzt oder wenn Rauch oder ungewöhnliche Gerüche auftreten, ziehen Sie sofort das Netzkabel ab.**



CAUTION:

- Versuchen Sie nicht, QuickGene-Mini8L ohne die Erlaubnis des Herstellers zu verändern. Dadurch könnte es zu einem Brand oder Stromschlag kommen.
- Legen Sie keine Gegenstände auf QuickGene-Mini8L ab, und lassen Sie keine Gegenstände darauf fallen. Setzen Sie es außerdem keinen Stößen oder ähnlichen Erschütterungen aus, da es dadurch zu einem Ausfall oder zu einer Fehlfunktion von QuickGene-Mini8L kommen könnte.
- Wenn im Gerät irgendwelche Flüssigkeiten zurückbleiben, wischen Sie es mit einem weichen Papiertuch aus. Andernfalls kann es zu einer Beschädigung von QuickGene-Mini8L kommen.
- Tragen Sie beim Auswechseln der Druckmessköpfe stets Handschuhe.
- Falls Ethanol in das Gerät verschüttet wird, ziehen Sie sofort das Netzkabel ab.
- Reparaturarbeiten an QuickGene-Mini8L sollten nur von Firmen ausgeführt werden, die von der KURABO INDUSTRIES LTD. ausdrücklich dafür autorisiert sind.
- Dabei sollten nur Original-Ersatzteile von der KURABO INDUSTRIES LTD. verwendet werden.
- Wenn das Gerät anders als auf die vom Hersteller vorgesehene Weise verwendet wird, können die Sicherheitseigenschaften des Geräts beeinträchtigt werden.

Über Isolations-Kits

Nachstehend als „Kit/Kits“ bezeichnet.



CAUTION:

- Nähere Informationen zum Umgang mit den Kits finden Sie im entsprechenden Handbuch.
- Der Umgang mit den Reagenzien in den Kits sollte unter Befolgung der Sicherheitshinweise und Vorsichtsmaßnahmen des jeweiligen Kits erfolgen.
- Die Extraktion sollte in einem geeigneten Laboratorium oder einem entsprechendem Arbeitsplatz durchgeführt werden.

Isolations-Kits

Für DNA	DNA Vollblut Kit / DB-L
	DNA Gewebe Kit / DT-L

Note:

Die Kits werden nicht mit QuickGene-Mini8L ausgeliefert. Wählen Sie die gewünschten Kits aus und bestellen Sie sie getrennt.

Über nicht in den Kits enthaltene Reagenzien



CAUTION:

- Beim Umgang mit einem Reagens, das nicht in den Kits enthalten ist, sind die Sicherheitsinformationen und Vorsichtsmaßnahmen des jeweiligen Reagens zu befolgen.
- Die Extraktion sollte in einem geeigneten Laboratorium oder an einem entsprechenden Arbeitsplatz durchgeführt werden. Mit einigen Reagenzien sollte in einer Abzugskammer gearbeitet werden.

Über Reinigungs-/Waschlösung



CAUTION:

- Bei der Anwendung von Reinigungs-/Waschlösungen beim QuickGene-Mini8L und den Zubehöerteilen sind die Sicherheitsinformationen und Vorsichtsmaßnahmen für die Lösung zu beachten.
- Halten Sie Ethanol fern von Feuer. Es ist leicht entflammbar.



BIOHAZARD :

- Beim Reinigen/Waschen immer geeignete Handschuhe, einen Mundschutz und eine Schutzbrille tragen.

Über die Proben



BIOHAZARD :

- Beim Umgang mit infektiösen Proben immer geeignete Handschuhe, einen Mundschutz und eine Schutzbrille tragen.

Einschränkungen der Produktverwendung

- Die KURABO INDUSTRIES LTD. übernimmt keine Haftung für die Ergebnisse, unabhängig von der Anwendung.
- Es liegt in der Verantwortung des Anwenders, die Eignung des Isolations-Kits und QuickGene-Mini8L zu überprüfen.
- QuickGene-Mini8L ist nur für den Einsatz in Forschung und Lehre vorgesehen.

Wenn Sie QuickGene-Mini8L einsetzen, lesen Sie diese Anleitung sorgfältig durch, und befolgen Sie die Sicherheitsbestimmungen Ihrer Einrichtung (Labor).

INDEX

1 Setting Up

This chapter explains how to set up QuickGene-Mini8L.

2 Operation

This chapter explains the extraction procedures.

3 Maintenance

This chapter explains how to maintain QuickGene-Mini8L.

4 Troubleshooting

This chapter describes the procedures that should be taken when you suspect device failures.

5 Main Specifications

This chapter describes the basic specifications of QuickGene-Mini8L.

Appendix A

This chapter describes after-sales services and points to note for transportation.

Contents

1 Setting Up **p. 1**

- 1.1 Operating Environment/Use Conditions
- 1.2 Checking QuickGene-Mini8L and Accessories
- 1.3 Removing the Packing Materials
- 1.4 Overall View
- 1.5 Basic Functions
- 1.6 Precautions on Transportation
- 1.7 Precautions on Storage

2 Operation **p. 11**

- 2.1 Turning the Power ON or OFF
- 2.2 Preparation
- 2.3 Extraction

3 Maintenance **p. 27**

- 3.1 Cleaning QuickGene-Mini8L
- 3.2 Cleaning the Parts
- 3.3 How to Clean/Replace the Pressure Adapter
- 3.4 How to Clean/Replace the Pressure Heads

4 Troubleshooting **p. 31**

5 Main Specifications **p. 33**

Appendix A **p. 35**

- A.1 Optional Parts/Replacement
- A.2 Product Guarantees
- A.3 About Services
- A.4 Contact Us
- A.5 Notes for Transporting/Shipping QuickGene-Mini8L
- A.6 Disposal of Device

1 Setting Up

This chapter explains how to set up QuickGene-Mini8L.

1

1.1 Operating Environment/Use Conditions

This section explains the operating environment and use conditions of QuickGene-Mini8L.

■ Operating environment



WARNING:

- Do not use QuickGene-Mini8L to a location where it can be splashed with water. It may cause a device failure, fire, or electric shock.
- When relocating QuickGene-Mini8L, disconnect the plug from the outlet first. If the power cable is damaged, this may cause a device failure, fire, injury, or electric shock.



CAUTION:

- Do not use QuickGene-Mini8L in an unstable place such as a slanted surface or a place subject to vibrations. It may cause injury or device failure.
- Do not use QuickGene-Mini8L in direct sunlight or close to a heating device. It may shorten the life of QuickGene-Mini8L, or cause a trouble.

For correct and safe use of QuickGene-Mini8L, use it in a location that meets the following conditions:

- The space shown in the following figure must be allocated.



- A location where power can be provided (This is a Class II device. Be sure to use the attached AC adapter.)
- A location where the temperature is 15 to 30 °C, and humidity is 30 to 80%RH (non-condensing)
- A location that is flat and stable, with no vibration
- A location away from direct sunlight (Block the sunlight by closing curtains or blinds as necessary.)
- A location which is well-ventilated and not dusty
- A location where the temperature does not go up and down suddenly (Warming a cold room suddenly or moving QuickGene-Mini8L from a room with low temperature to a

warm room may cause condensation inside the device, resulting in abnormal extraction.)

- A location where the temperature and humidity are kept within the specified range (far from water taps, water heaters, humidifiers, air-conditioners and heaters)
- A location far from objects with generates strong magnetic fields (motors, transformers, TV, audio speakers, magnets, etc.) (Bringing QuickGene-Mini8L close to any type of magnetic field may cause a malfunction.)


■ Use conditions

Items		Specifications
Temperature (°C)	During operation	15~30
	During downtime	15~30
Humidity (%)	During operation	30~80
	During downtime	10~80
Max. wet bulb temperature (°C)	During operation	29 (non-condensing)
	During downtime	29 (non-condensing)
Temperature gradient (°C / Hr)		12 or less (non-condensing)
Humidity gradient (% / day)		30 or less (non-condensing)
Altitude, operating (m)		1600 or less

1.2 Checking QuickGene-Mini8L and Accessories

Check that the following are included in the package.

Contact the local representative if you notice any missing part(s).

☐ QuickGene-Mini8L	☐ Operation Manual	☐ AC Adapter
		
☐ Power Cable (US/ Canada)	☐ Cartridge Holder	☐ Tube Holder
		
☐ Pressure Seal Plate (× 2)		
		



CAUTION:

Note: Use an appropriate power cable by following the descriptions below.

US/Canada: Use the power cable included in the package.

Other countries: The power cable is not included in the package. Prepare the power cable that meets your country's standard.

The specification of the power cable for QuickGene-Mini8L is as follows.

100-120V area

Power Voltage: 100 to 120 V

Requirements for the plug/connector: AC 125 V 1A

Requirements for the cable: SJT 2 x 18 AWG 60°C

200-240V area

Power Voltage: 200 to 240 V

Requirements for the plug/connector: AC 250 V 1 A

Requirements for the cable: CENELEC 2 x 0.75 mm² 70°C


1.3 Remove the Packing Materials

Refer to the attached file.


1.4 Overall view

This section explains the name and function of each part in QuickGene-Mini8L.

■ Front view



■ Rear view



1

■ Pressure seal plate



Surface



Back side



Packing

■ Cartridge Holder



■ Tube Holder



1.5 ml microtube

(Not supplied with QuickGene-Mini8L)



Waste Tube

(Not supplied with QuickGene-Mini8L)



Cartridge

(Not supplied with QuickGene-Mini8L)



■ Label



ON/OFF Mark

Name	Description
ON / OFF Mark	ON Mark: Rotating the switch to the ON Mark starts pressure application. OFF Mark: Rotating the switch to the OFF Mark finishes pressure application.

■ Pressure Control Switch



– Switch


Pressure value

+ Switch

Name	Description
– Switch	Press to lower the pressure value
+ Switch	press to raise the pressure value
Pressure value	About the setting range, refer to [1.5 Pressure Parameters]

■ Biohazard Risk Symbol Label

This caution symbol indicates a possible biohazard risk from patient specimen contamination.



Biohazard Risk Symbol Label

1.5 Basic Functions

The following describes the main components of QuickGene-Mini8L.

Component	Function
Main Unit 	Start/stop putting pressurized air into Cartridges by operating the Rotary Switch. Pressure application automatically stops in about one minute. (Pressure value can be changed using Pressure Control Switch.) Operating state is indicated by the lamp (LED). When the power is turned on, the lamp (LED) lights. During pressure application, the lamp (LED) blinks. The main unit contains a pump for pressurizing air, a sensor for detecting start/stop of pressure application, and a circuit for controlling the duration of pressure application.
Pressure Unit 	Put pressurized air into the Cartridges through the pressure heads. When the rotary switch is turned on, the pressure heads move down to the Pressure Seal Plate to put pressurized air into Cartridges.
Holder Unit 	The holder unit is comprised of the Cartridge Holder, Tube Holder and 2 pcs of Pressure Seal Plate. Lysate/Wash Buffer/Elution Buffer put in a Cartridge passes through the filter in the Cartridge by pressurized air and filtered solution drops into the Waste Tube or 1.5 ml microtubes. Note: Pressure application of lysate and wash, and that of elution operation are switched by moving the position of the Cartridge Holder manually.

■ Lamp (LED) indication information

The following describes the lamp (LED) indications.

Lamp (LED) indication	Description
ON	Indicates that the power is ON and pressure application can be performed.
Blink	Indicates that pressure application is in progress. Note: When pressure application is completed, the lamp (LED) indication returns to the ON state.

■ Pressure Parameters

Pressure parameter can be changed by the Pressure Control Switch.


Pressure value	
0	Pressure time: 40sec / no buzzer sound
1	Pressure time: 50sec / no buzzer sound
2	Pressure time: 60sec / no buzzer sound
3 (Initial setting value)	Pressure time: 70sec / no buzzer sound
4	Pressure time: 80sec / no buzzer sound
5	Pressure time: 40sec / buzzer after pressure processing
6	Pressure time: 50sec / buzzer after pressure processing
7	Pressure time: 60sec / buzzer after pressure processing
8	Pressure time: 70sec / buzzer after pressure processing
9	Pressure time: 80sec / buzzer after pressure processing

1.6 Precautions on Transportation

When transporting QuickGene-Mini8L, note the following points.

- Be sure to hold the Handles.
- Do not hold the Rotary Switch.
- Do not touch Pressure Head section.
- Remove all the holders before transportation.

Be sure to hold the handles.



1.7 Precautions on Storage

When storing QuickGene-Mini8L, note the following points.

- Do not keep it with the Rotary Switch adjusted to the position of turning on with Cartridges set in the Cartridge Holder.
- When the outside of the QuickGene-Mini8L is heavily soiled, clean it.
- If the machine will not be used for a long time, clean then cover it before storing.

2 Operation

This chapter explains how to operate QuickGene-Mini8L and shows the flow of extraction.



BIOHAZARD:

Always wear appropriate gloves, a mask, and safety goggles during any biohazardous operations in extraction process. Even when touching the device after any operation with a biohazard risk, wear appropriate gloves and a mask since the device may be contaminated.

Important: Before starting extraction, put on appropriate gloves, a mask, and safety goggles if required by the operation. In the operation from preparing samples to extraction completion, be careful not to contaminate the samples with sweat, saliva, etc.


2

2.1 Turning the power ON and OFF

This section explains how to turn the power of QuickGene-Mini8L on and off.


Note: Since QuickGene-Mini8L is not equipped with a power switch, the power is turned on/off by connecting/disconnecting the power cable.

■ Turning on the power



- (1) Make sure that the AC adapter and power cable are connected securely, and the plug of the AC adapter is securely connected to the QuickGene-Mini8L.

Note: QuickGene-Mini8L is a Class II device. Be sure to use the attached AC adapter.



- (2) Connect the plug of the power cable to the outlet.
The QuickGene-Mini8L turns on and the lamp (LED) lights.

■ Turning off the power



Plug

- (1) Disconnect the plug of the power cable from the outlet.

The lamp (LED) turns off, then the QuickGene-Mini8L turns off.

Note:

Do not place any objects near the outlet so that the plug of the power cable can be disconnected immediately in case of emergency.

2.2 Preparation

The following preparations are required for extraction operation.

■ Items to be prepared

- Gloves
- Mask
- Safety Goggles
- 1.5 ml microtubes
- Waste Tubes (WT) *
- Cartridges (CA) *
- Buffer (Wash Buffer, Elution Buffer) *
- Lysate (Samples)

For the preparation of samples, refer to the handbook of each kit.

* : Provided with QuickGene Isolation Kits

■ Preparation of lysate

Make lysate using the specified kit for each target samples.

For details, refer to the handbook of the Isolation Kits.

2.3 Extraction

This section explains extraction procedure including before and after extraction operations.

Be sure to perform extraction in the following order.

Note: Use the provided Cartridges and Waste Tubes in the Isolation Kit.


■ Before Extraction Operation

2



- (1) Turn on the power by connecting the power cable and then make sure the lamp (LED) lights.

Lamp (LED): ON



- (2) Prepare the Cartridge Holder, Tube Holder, Pressure Seal Plate.




Tube Holder

- (3) Set the Waste Tubes and 1.5 ml microtubes into the Tube Holder in order.

Important:


Keep the Holder Handle of the Tube Holder toward the front side when setting the Waste Tubes and 1.5 ml microtubes as shown in below figure.




Waste Tubes



Holder Handle




1.5 ml microtubes



2

- (4) Set the Waste Tubes and 1.5 ml microtubes into the Tube Holder in order. Then insert the Cartridge Holder into the correct position of the Tube Holder.




Insert the bottom
bulges of
Cartridge Holder
into the side
notches of the
Tube Holder.

Important:

- Make sure the bulges of Cartridge Holder are inserted into the side notches of the Tube Holder.
- If their position does not correspond, Buffer and/or lysate may spill. This results in an extraction failure, and Buffer and/or lysate becoming waste.



Cartridge Holder




Cartridge


- (5) Set the Cartridges in the Cartridge Holder so that the position (No.) of each tubes is the corresponding position in (3). Check the location of Waste tubes, 1.5 ml microtubes and Cartridges.

Important:

- Align the taps on the Cartridge with the grooves into the notch of Cartridge Holder and then push into the bottom position. If the Cartridge is not inserted in correct position, it may cause the pressure leakage.
- If their position does not correspond, Buffer and/or lysate may spill. This results in an extraction failure, and Buffer and/or lysate becoming waste.



■ Extraction



<Applying Lysate to Cartridges>

(1) Apply lysate to each Cartridge.

Transfer the lysate into the Cartridges by decantation or using pipette. In this operation, take care not to touch the filter in the Cartridge, the rim of Cartridge.

Note:

If any lysate is left on the rim of a Cartridge or on the Cartridge Holder, wipe it off with a soft paper tissue (Refer to “3 Maintenance”).



(2) Set the Pressure Seal Plate covering the Cartridges.


Important:

- Keep the stainless steel side up, the silicone rubber (Packing) side down and the Packing towards to the Cartridges while setting the Pressure Seal Plate.
- Check the position of Pressure Seal Plate to make sure the both ends of Pressure Seal Plate are inserted in the notches of Cartridge holder.


Note:

Do not use the soiled Pressure Seal Plate.

If the Pressure Seal Plate gets dirty, clean it before using (Refer to “3.2 Cleaning the Parts”).



(3) Set the Cartridge Holder and Tube Holder into QuickGene-Mini8L. Make sure that the first row of Cartridge/Tube Holder unit is placed at the stopper which located just under the Pressure Head inside the machine with a gentle push.



- (4) Rotate the rotary switch toward the front side to lower the Pressure Heads.

Important:

Use both hands to rotate the rotary switch.

Rotate down to here.

- (5) The lamp (LED) blinks and pressurized air is put into the Cartridges row by row.

Note:

- When the solution in each Cartridge is discharged completely before pressure application automatically stops, return the rotary switch to the original position to terminate pressure application (Refer to step (7)).
- Pressure application automatically stops in about 70 seconds. Pressuring time can be changed through the Pressure Mode Switch (Refer to p.7).



Before pressurizing



After pressurizing

- (6) Make sure that the lysate does not remain in the Cartridges.

Important:

Make sure that no liquid remains in the Cartridges.

Note:

- If any solution remains in the Cartridges even after about 70 seconds has elapsed, return the rotary switch to the original position (Lamp (LED): ON) and then rotate it toward the front side (Lamp (LED): Blink) to put pressurized air into the Cartridges again.
- If the rotary switch is returned swiftly to the original position, it may result in the splashing or solutions. Accordingly, rotate the rotary switch slowly.



- (7) Return the rotary switch to the position OFF to raise the pressure heads.

Note:

Do not pull out the Holder unit while the pressure heads are lowered.

Important:

Use both hands to rotate the rotary switch.

Rotate up to here.

2



- (8) Repeat the pressure process for the other rows of the Cartridges.


Note:

Refer to step (3) to (7).



- (9) Pull out the Cartridge / Tube Holder.

2



The holes of Pressure Seal Plate



<Wash>


(10) Apply Wash Buffer to each Cartridge.

Use the pipette to apply Wash Buffer to each Cartridge through the hole of the Pressure Seal Plate. In this operation, take care not to touch the Cartridges.

If the above procedure is difficult, hold the two ends of the pressure seal plate and rotate the plate from the front to the back of the holder by 90°. While standing, insert the plate into the notches at the top of the cartridge holder and add the Wash Buffer. In this operation, take care not to touch the Cartridge or the packing (back) of the pressure seal plate with the pipette. Once the Washing Buffer has been added to the Cartridges, rotate the pressure seal plate 90° to return to the original condition.

Note:

If any Wash Buffer is left on the Pressure Seal Plate, wipe it off with a soft paper tissue.


Pressure Seal Plate
Packing (back)

notches

(11) Rotate the rotary switch then pressurized air is put into the Cartridges to perform the wash process.

Note:

Refer to Step (3) to (8).

Important:

Use both hands to rotate the rotary switch.

(12) Repeat the wash process the necessary number of times in correct rows according to the protocols.

Note:

Refer to Step (10) to (11).



(13) After wash process is completed, return the rotary switch to the “OFF” position to raise the pressure heads.

Important:

- Use both hands to rotate the rotary switch.
- Make sure that no liquid remains in the Cartridges.
- Make sure that the Pressuring time of the last wash process for at least 70 seconds. If the Pressuring time was changed, return to original setting (70 seconds) through the Pressure Mode Switch (Refer to page 7 [Pressure Control Switch] and 9 [Pressure Parameters]).


Note:

Do not pull out the Holder unit while the pressure heads are lowered.



(14) Pull out the Cartridge/Tube Holder.

Use both hands




Cartridge Holder

Tube Holder



Set here.



Insert the bottom
Bulges of Cartridge
Holder into the side
notches of the
Tube Holder.



<Elution>

(15) Lift the Cartridge Holder up to separate from the Tube Holder and set the Cartridge Holder to the correct position of the Tube Holder. In this operation, correct position means that the tip of Cartridge is on the 1.5 ml microtubes.


Note:

- Use both hands to move the Cartridge Holder.

(16) Insert the Cartridge Holder into the side notches of the Tube Holder.

Note:

- Use both hands to set the Cartridge Holder.
- Set the Cartridge Holder gently, otherwise liquid may splash.



Pressure seal
plate
packing (back)

notches

(17) Apply Elution Buffer to each Cartridge.

Use the pipette to apply Elution Buffer to each Cartridge through the hole of the Pressure Seal Plate. In this operation, take care not to touch the Cartridges.

If the above procedure is difficult, hold the two ends of the pressure seal plate and rotate the plate from the front to the back of the holder by 90°. While standing, insert the plate into the notches at the top of the cartridge holder and add the Elution Buffer. In this operation, take care not to touch the Cartridge or the packing (back) of the pressure seal plate with the pipette. Once the Elution Buffer has been added to the Cartridges, rotate the pressure seal plate 90° to return to the original condition.

2

Important:

Make sure that apply the Elution Buffer after setting the Cartridge Holder onto the Tube Holder.

Note:

If any Elution Buffer is left on the Pressure Seal Plate, wipe it off with a soft paper tissue.



(18) Rotate the rotary switch then pressurized air is put into the Cartridges to perform the elution process.

Note:

Refer to Step (3) to (8).

Important:

Use both hands to rotate the rotary switch.

2




(19) After elution process is completed, return the rotary switch to the “OFF” position to raise the pressure heads.

Important:

- Use both hands to rotate the rotary switch.
 - Make sure that no liquid remains in the Cartridges.
-

Note:

Do not pull out the Holder unit while the pressure heads are lowered.



(20) Pull out the Cartridge / Tube Holder.

■ After Extraction Operation



- (1) Remove the pressure seal plate from the Cartridge Holder. Then remove and waste the Cartridges from the Cartridge Holder.


Note:

Dispose of the Cartridges according to appropriate laws and rules.




BIOHAZARD: Dispose of infectious waste according to your biological safety manuals.

2



Disposal
Cartridge


Use both hands



- (2) After disposing of all cartridges, lift and separate the Cartridge Holder from Tube Holder.

Note:

- Use both hands to remove the Cartridge Holder.



microtubes

- (3) Remove 1.5 ml microtubes and put caps on them.



Waste
Tube

- (4) Remove the Waste Tubes from the Tube Holder, and dispose of them.

Note:

- Dispose of the Waste Tubes and waste solution according to appropriate laws and rules.



BIOHAZARD: Dispose of infectious waste according to your biological safety manuals.

2

3 Maintenance

To use QuickGene-Mini8L properly, check whether or not each part is clean and in normal condition before use. If necessary, perform cleaning and/or parts replacement referring to the descriptions in this chapter.

3.1 Cleaning QuickGene-Mini8L

This section explains how to clean QuickGene-Mini8L.



BIOHAZARD:

When cleaning QuickGene-Mini8L, wear appropriate gloves, a mask, and safety goggles.



WARNING:

Before starting the maintenance work, turn off the power of QuickGene-Mini8L and disconnect the power plug from the outlet. Otherwise it may cause an electric shock.



Parts to clean	Cleaning methods
Body (outside)	Remove dust gently with a dry, soft cloth. If the outside of the device is heavily soiled, or if any samples that may cause infection are adhered to the outside of the QuickGene-Mini8L, wipe with a soft paper tissue, soaked with 0.1% sodium hypochlorite solution or ethanol.
Body (inside)	
Pressure Head	Wipe with a soft paper tissue, soaked with 0.1% sodium hypochlorite solution or ethanol.
Note: If the pressure heads are heavily soiled or any abnormal conditions (damage, deformation, hardening, etc.) are found, replace them with new ones (P.28-30).	



CAUTION: Keep ethanol away from fire when using. It is highly flammable.

3.2 Cleaning the Parts

The following table describes how to clean the Parts of QuickGene-Mini8L.

Parts	Cleaning methods
Cartridge Holder	Clean the parts with neutral detergent then wash out with 0.1% sodium hypochlorite solution. Next, wash the solution out with DEPC water and then dry the parts.
Tube Holder	
Pressure Seal Plate	

3.3 How to replace the Pressure Adapter


3




- (1) Turn off the power.
Disconnect the plug of the power cable from the outlet.



- (2) Pull out the Cartridge Holder and Tube Holder.



- (3) Hold the pressing type knobs of both sides of the Pressure Adapter as shown in the figure, and then press the upper knobs in the direction of the arrow.



- (4) While pressing the upper knobs, take the upper protruding parts out of the QuickGene-Mini8L as shown.

Note:

Do not use excessive force otherwise it may cause the Pressure Adapter failures.



Upper protruding parts



- (5) Take out the lower protruding parts of Pressure Adapter in the direction as shown.



Lower protruding parts


- (6) Set the Pressure Adapter in the reverse order to removal (3) ~ (5).

Note:

Do not use excessive force otherwise it may cause the Pressure Adapter failures.

3.4 How to replace the Pressure Heads

(1) First, take out the Pressure Adapter (P.28-29).



(2) Lying the QuickGene-Mini8L face up as shown and then rotate the Rotary Switch to eject the Pressure Heads.

Note: Before lying the device face up, spread a cloth, etc. on the table to avoid damaging the body.

3



(3) While holding the QuickGene-Mini8L by one hand, remove the Pressure Heads.



(4) While holding the QuickGene-Mini8L by one hand, insert new Pressure Heads.

Note: Set the Pressure Heads in the direction shown in the figure, and push them completely into the body.



(5) Rotate the Rotary Switch to retract the Pressure Heads.

(6) Install the Pressure Adapter into the device (Step.6→p. 28).

4 Troubleshooting

This chapter explains the procedures that should be taken when you suspect device failures.

Phenomenon	Cause	Appropriate action
The lamp (LED) does not light.	• The power plug is not connected to the outlet. • The AC adapter is not connected to QuickGene-Mini8L. • The power cable is not connected to the AC adapter.	• Connect the power plug to the outlet completely. • Connect the AC adapter to QuickGene-Mini8L completely. • Connect the power cable to the AC adapter completely.
The solution put in Cartridges does not steadily drop into the Collection Tubes or Waste Tubes.	• Cartridges are incorrectly inserted into the cartridge holder.	• Insert the Cartridges completely into the cartridge holder (p.16). • Set the Collection and Waste Tubes corresponding to the position of the Cartridge to be inserted (p.16).
	• Pressure heads / pressure adapter / pressure seal plate are incorrectly installed.	• Install the pressure heads / pressure adapter / pressure seal plate correctly (p.17, p.28-30) .
	• Pressure heads / pressure adapter / pressure seal plate have become deformed or hardened.	• Replace the pressure heads / pressure adapter / pressure seal plate with new ones (p.28-30) .
Pressure application does not start even after rotating the rotary switch toward the front side.	• QuickGene-Mini8L may have a mechanical or electrical problem.	Contact your local representative.
QuickGene-Mini8L emits an abnormal noise.	• QuickGene-Mini8L may have a mechanical or electrical problem.	Contact your local representative.
QuickGene-Mini8L emits an abnormal smell.	• QuickGene-Mini8L may have a mechanical or electrical problem.	Turn off the power immediately by disconnecting the power cable from the outlet and then contact your local representative.

5 Main Specifications

The following describes the main specifications of QuickGene-Mini8L.

■ Main specifications

Item	Specifications
Model name	QuickGene-Mini8L
Dimensions	280mm (W) × 255mm (D) × 295mm (H)
Weight	Approx. 3.3kg (Main body)
Samples	Max. 8 can be processed simultaneously
Range of temperature and relative humidity	Temperature: 15 ~ 30°C Humidity: 30 ~ 80% (non-condensing)

■ Power supply conditions

• AC Adapter

Item	Specifications
Rated input voltage	AC100V~240V
Voltage fluctuation range	±10%
Phase	Single
Power frequency	50 – 60Hz
Rated input current	1A
Output voltage	DC12V

• Main unit


Item	Specifications
Rated voltage	DC12V ± 5%
Rated current	0.5A

■ Environmental conditions

Item	Specifications
Usage environment	Indoor use only
Overvoltage category definition	Transient overvoltage category II
Pollution degree	Pollution Degree 2
IP	IPX0

Appendix A

A.1 Replacement/Optional Parts

Name : Cartridge Holder P/N : 40321301410	Name : Collection Holder P/N : 40321301411	Name : Pressure Seal Plate (2pcs.) P/N : 40321301413
		
Name : Pressure Adapter Set P/N : 40321301412	Name : Pressure Heads (8pcs.) P/N : 40321300451	Name : AC Adapter P/N : 40321301406
		

A.2 Product Guarantees

- The guaranty period shall be one year from the delivery of the product.
- Any part which fails to function properly under normal use, provided that all warnings and cautions in this manual are observed, during the guarantee period will be repaired by KURABO INDUSTRIES free of charge.
- If the problem is due to the causes listed below, some charge may be applied for the repair even within the guarantee period.
 - Any failures due to improper use or that are affected by other devices except for those approved by KURABO INDUSTRIES.
 - Any malfunctions or damages during transportation or due to dropping of the product by user.

A.3 About Services

- Before you ask for device repairs, refer to “4 Troubleshooting (P.31)” to check the problems. If the problems cannot be solved, contact your local representative, or the relative customer support.

A.4 Manufacturer Information

KURABO INDUSTRIES LTD.
Advanced Technology Division
Bio-Medical Department

Kurabo Neyagawa Techno Center 3F, 14-5, Shimokida-Cho, Neyagawa,
Osaka 572-0823, Japan

TEL. 072-820-3079 FAX. 072-820-3095 URL; <http://www.kurabo.co.jp/bio/>

A.5 Notes for Transfer QuickGene-Mini8L

When transferring the QuickGene-Mini8L, perform the following tasks:



Warning:

Before carrying QuickGene-Mini8L, disconnect the plug from the outlet first. Watch your step when you relocate the QuickGene-Mini8L. If the power cable is damaged, this may cause a device failure, fire, injury, or electric shock.

When transporting/shipping QuickGene-Mini8L, be sure to perform the following tasks:

Remove all attached parts (cartridge holder and collection holder) from QuickGene-Mini8L. Place the cushion removed at the time of unpacking onto the pressure heads and then secure the cushion and rotary switch with tape (Refer to “1.3 Remove the Packing Materials (P.4)”). After completing the above tasks, pack QuickGene-Mini8L in its original shipping box or some other equivalent box.

A.6 Disposal of Device



Do not put in the trash.

Recycle or dispose of according to local, state, or federal laws.



Nucleic Acid Isolation Device QuickGene-Mini8L Operation Manual

Date of issuance: March, 2018

KURABO INDUSTRIES LTD.

Printed in Japan

- The contents of this manual may be updated without notice.
- KURABO INDUSTRIES LTD assumes no liability for damages to third party copyrights or other rights arising from the use of any information in this manual.
- Contents of this manual are not to be reproduced without permission from KURABO INDUSTRIES LTD.
- Manuals with missing or wrongly collated pages will be replaced free of charge.

Should you have questions concerning your Kurabo system, please contact our experienced ADS Biotec Support Team using the information below.

ADS Biotec Inc	ADS Biotec Limited*
ADS Biotec Inc. 7409 Irvington Rd Omaha, NE 68122, USA Phone: (888) 233-9283 • (402) 800-3208 Fax: (402) 800-3183 Email: support@adsbiotec.com	ADS Biotec Limited 40 Watt Road, Hillington Park Glasgow G52 4RY, UK Phone: +44 (0) 141 892 8800 Fax: +44 (0) 141 883 5967 E-mail: support@adsbiotec.com
*Registered in England and Wales. Registered Office: Birketts LLP 22 Station Road Cambridge CB1 2JD. Registration No. 03257373	
ADS BIOTEC INC and ADS BIOTEC LIMITED are authorized by Kurabo Industries as distributors of the Kurabo equipment and consumables.	

ADS BIOTEC and YOUR PATH TO DISCOVERY are trademarks of ADS BIOTEC INC. All other trademarks are trademarks of their respective owners. All rights reserved. ©2018. Printed in USA.



KURABO INDUSTRIES LTD.